

### Series 70 eSTS

1600A, 2-source, 4-pole, 4-wire, SMR eSTS





KLLSG-1 CB1



NOTE 2

PROVIDED BY OTHERS



#### NOTE 1:

Fuse holders, Phases (A/B) and ground terminal blocks are provided by LayerZero Power Systems.

Fuses are NOT provided by LayerZero Power Systems.

Fuse holder Part Number: ABB, E 91/32 Ground Terminal Block Part Number: PHOENIX CONTACT, USLK10 N

All internal wiring to fuse holders and ground terminal blocks are provided by LayerZero Power System in accordance with Bloom energy Electrical One Line Document No. DOC-1010311.

Conductor size: 1-#10 AWG per Phase. 1-#10 AWG per Ground.

#### NOTE 2:

- 1- Locks to be installed in a manner with BOTH keys withheld when LSG-1 CB1 is in ON state. Lock to be installed internally into breaker or through external bolt means.
- 2- Bolt locks may not work on pushbutton style circuit breakers.

#### ADDITIONAL INFORMATION:

- 1. Copper compression-type cable lugs recommended for all power
- 2. Input terminals are NEMA 2-hole pattern with 0.5 inch diameter holes spaced 1.75 inches apart
- 3. Input terminals provided at the top and bottom
- 4. Neutral Rating: 100%

LEGEN	D		
A	CURRENT METERING POINT	K#)	KIRK KEY (INTERNAL TOCB)
v	VOLTAGE METERING POINT	K#)	KIRK KEY TRANSFER BLOCK
PQ	POWER QUALITY METERING POINT	(K#) (K#)	
	I AMED ZEDO	Р	AGE DESCRIPTION

	LAYER	PAGE DESCRIPTION		
	POWER SYS	STEMS, INC.	ONE LINE DIAGRAM, eSTS	
JOB	DRAWN	DATE 10/24/2018	DWG NO	REV
LZ-10905	СНК	DATE	94-ES-10905-1	В
	APPR	DATE	SHEET 1 OF 5	

#### STS AND BYPASS SWITCHBOARD SEQUENCE OF OPERATION COMPONENTS

#### STARTING POSITIONS:

NOTE: 7 (SEVEN) LOCKS AND 5 (FIVE) KEYS (PROVIDED BY LAYERZERO POWER SYSTEMS)

KL101 PAIRED WITH KEY 1. KEY 1 IN KL101

KL102 PAIRED WITH KEY 2. KEY 2 IN KL102

KL201 (EMPTY), PAIRED WITH KEY 4

KL202 (EMPTY), PAIRED WITH KEY 5

KT1 PAIRED WITH KEY 2, KEY 3 & KEY 4. KEY 3 & KEY 4 IN KT1. KEY 2 (EMPTY)

KT2 PAIRED WITH KEY 1, KEY 3 & KEY 5. KEY 5 IN KT2. KEY 3 (EMPTY) & KEY 1 (EMPTY)

KLLSG-1 PAIRED WITH KEY 1 & KEY 4. KEY 1 (EMPTY) & KEY 4 (EMPTY)

#### OPERATION:

NOTE: OPERATION IS A BREAK BEFORE MAKE, PROTECTING A CROSS CONNECTION.

- PLACE STS INTO SOURCE 1 UTILITY BYPASS POWER PATH
- OPEN STS SOURCE 2 CB (CB102)
- OPERATE KEY 2 IN KL102 TO ENGAGE LOCK ON CB102

KEY 2 WILL BE RELEASED

- REMOVE KEY 2 FROM KL102, PLACE IN TRANSFER BLOCK KT1 AND OPERATE TRANSFER BLOCK KT1

KEY 2 & KEY 3 WILL BE HELD IN TRANSFER BLOCK KT1

KEY 4 WILL BE FREE TO OPERATE

- OPERATE KEY 4 IN KL201 TO ENGAGE UNLOCK SOURCE 1 BYPASS (STS CB201)

KEY 4 WILL BE HELD IN STS BYPASS CB (CB201)

- CLOSE STS BYPASS CB (CB201)
- OPEN STS OUTPUT CB301
- OPEN STS UTILITY SOURCE CB 101
- OPERATE KEY 1 IN LOCK KL101

STS UTILITY SOURCE CB (CB101) WILL BE HELD IN OPEN POSITION

**KEY 1 WILL BE RELEASED** 

- REMOVE KEY 1 FROM KL101 (CB101) PLACE IN LOCK KLLSG-1 CB1
- OPEN STS BYPASS (CB201)
- OPERATE KEY 4 in LOCK KL201

STS BYPASS (CB201) WILL BE HELD IN OPEN POSITION

**KEY 4 WILL BE RELEASED** 

- REMOVE KEY 4 FROM KL201 (CB201) PLACE IN LOCK KLLSG-1 CB1
- OPERATE KEY 4 IN LOCK KLLSG-1 CB1


LSG-1 CB1 WILL BE ALLOWED TO BE CLOSED


KEY 4 & KEY 1 WILL BE HELD IN LOCK KLLSG-1 CB1

- CLOSE LSG-1 CB1
- OPERATION TO BE PERFORMED IN REVERSE TO REVERT BACK TO STARTING POSITION.

LZ-JOB	Location	Item Master Number	Lock Number	Key Removable Position	STAMP Key Interchange
10905-1	CB101	KCAM00010	22800	Extended	K1
10905-1	CB201	KCAM00010	22802	Extended	K4
10905-1			22802	With held	K4
10905-1	KT1	KTR031	22803	Extended	K2
10905-1			22815	Extended	К3
10905-1			22815	Extended	К3
10905-1	KT2	KTR031	22800	Extended	K1
10905-1			22809	With held	K5
10905-1	CB202	KCAM00010	22809	Extended	K5
10905-1	CB102	KCAM00010	22803	Extended	K2
10905-1	LSG-1 CB1		22800		K1
10905-1	LSG-1 CB1		22802		K4

LAYERZERO POWER SYSTEMS, INC.		PAGE DESCRIPTION  ONE LINE DIAGRAM, eSTS		
JOB	DRAWN	DATE 10/24/2018	DWG NO	REV
LZ-10905	СНК	DATE	94-ES-10905-1	В
	APPR	DATE	SHEET 2 OF 5	







# **CUSTOMER INTERFACE BOARD (CIB)**

## SYSTEM STATUS CONTACT FIELD WIRING


CFI - CONTACT CLOSES FOR STATUS INDICATION OFI – CONTACT OPENS FOR STATUS INDICATION





## SYSTEM CONTROL FIELD WIRING

CFC - CONTACT CLOSES FOR CONTROL FUNCTION



#### NOTES:

- 1. TERMINAL NUMBERS REFER TO TERMINALS ON CUSTOMER INTERFACE BOARD (CIB).
- 2. TERMINALS SUITABLE FOR AWG 20-16 STRANDED COPPER WIRE, MAXIMUM ONE WAY LENGTH FOR #16: 500 ft (152 m).
- 3. ALL WIRING TO BE IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE AND ALL LOCAL CODES. CONTROL AND STATUS WIRING MUST BE RUN AND IN SEPARATE CONDUIT FROM POWER WIRING.
- 4. SYSTEM STATUS OUTPUTS ARE DRY, POTENTIAL-FREE CONTACTS. CUSTOMER REQUIREMENTS ARE AS FOLLOWS:
- a. Circuit voltage V < 250 V AC with current I < 12 A RMS, power factor = 1.0.
- b. Circuit voltage V < 200 V DC with current I < 0.4 A.
- 5. SYSTEM CONTROL INPUTS READ COMMANDS FROM EXTERNAL CONTACTS. CUSTOMER REQUIREMENTS ARE AS FOLLOWS:
- a. Dry, potential-free contacts.
- b. Form C
- c. Contacts are to be capable of switching 24 V DC at 5 mA < I < 10 mA.

8	LAYER POWER SYS		PAGE DESCRIPTION  ONE LINE DIAGRAM, eSTS	
JOB	DRAWN	DATE 10/24/2018	DWG NO	REV
LZ-10905	СНК	DATE	94-ES-10905-1	В
	APPR	DATE	SHEET 5 OF 5	